



Zoomer Jurassic World Indominus Rex Tail Tip Replacement

A quick guide to replace the tip of the Zoomer Jurassic World Indominus Rex's Tail

Written By: Luke Selby



INTRODUCTION

The mighty Indominus Rex, like any predator, has his own weaknesses. This time, the tip of his tail has broken! Let's get to work.



TOOLS:



- [Phillips #1 Screwdriver](#) (1)
 - [Heavy-Duty Spudger](#) (1)
-

Step 1 — Tail Tip



- ① Lay the toy on its back in order to have direct access to the screw holding the tail together.
- Remove the 9.4mm phillips screw from the tip of the tail.

Step 2



- Use a spudger to pry apart the pieces of the tail, and gently remove the two pieces of the tip for replacement.

To reassemble your device, follow these instructions in reverse order.

